


MAGMA GROOVE TERMINAL



GROOVE TERMINAL BOTTOM FOAMS

To adjust your controller to the proper height, use the recommended foam-set number(s) listed below:

FOAM-SET 1 (498 x 220 x 10 mm)

FOAM-SET 2 (498 x 220 x 12 mm)


FOAM-SET 3 (498 x 220 x 15 mm)

FOAM-SET 4 (498 x 220 x 20 mm)

FOAM-SET 5 (498 x 220 x 30 mm)

FOAM-SET 6 (498 x 220 x 50 mm)

FOAM-SET DDJ-REV7 example:



AlphaTheta XDJ-AZ (Required height: 50 mm)
FOAM-SET 6 (50 mm)

Pioneer XDJ-RX3 (Required height: 60 mm)
FOAM-SET 1 (10 mm) + **FOAM-SET 6** (50 mm)

Pioneer DDJ-REV7 (Required height: 75 mm)
FOAM-SET 1 (10 mm) + **FOAM-SET 3** (15mm) + **FOAM-SET 6** (50 mm)

Pioneer DDJ-REV-5 (Required height: 85 mm)
FOAM-SET 3 (15mm) + **FOAM-SET 4** (20 mm) + **FOAM-SET 6** (50 mm)

Pioneer DDJ-FLX10 (Required height: 82 mm)
FOAM-SET 2 (12 mm) + **FOAM-SET 4** (20 mm) + **FOAM-SET 6** (50 mm)

Denon Prime 4 / Prime 4+ (Required height: 50 mm)
FOAM-SET 6 (50 mm)

Denon SC Live 4 (Required height: 80 mm)
FOAM-SET 5 (30 mm) + **FOAM-SET 6** (50 mm)

Rane Four (Required height: 45 mm)
FOAM-SET 3 (15mm) + **FOAM-SET 5** (30 mm)

Rane Performer (Required height: 40 mm)
FOAM-SET 1 (10 mm) + **FOAM-SET 5** (30 mm)

Rane One / Rane One MK2 (Required height: 47 mm)
FOAM-SET 2 (12 mm) + **FOAM-SET 3** (15mm) + **FOAM-SET 4** (20 mm)

Rane System One (Required height: 45 mm)
FOAM-SET 3 (15mm) + **FOAM-SET 5** (30 mm)

More info:

